

LAMAX

X10 Taurus

Firmware update tutorial

Note - Camera must be connected to the charger by Micro USB cable during the entire update process to avoid interruption of the update due to the lack of battery power. Disrupting the update before it is completed can damage the camera permanently.

1. Format the Micro SD card and make sure it is empty.
2. Upload the file "firmware.bin" directly to the Micro SD card. (Do not create any folder but upload the file directly to the card.)
3. Insert the card with the uploaded file into the turned off camera.
4. Turn on the camera with the "On/Off" button.
5. Firmware begins to update. Blue LED flashes during the update. Do not push the buttons or take the battery out of the camera.
6. When the update is completed, the blue LED stops to flash (The update lasts approximately up to 1 minute.)
7. Disconnect the camera from the charger and remove the Micro SD card. Take the battery out of the camera and put it back inside after few seconds.
8. Turn on the camera. Camera will restart itself after few seconds.
9. In the camera menu, go to the "Firmware" section and check if the firmware is updated to version "LAMAX-X10-V1.3".